

# 





# REFINISH INTERIORS



# FORMULATED TO RESTORE OR CHANGE COLOR ON:

Flexible Plastic | Rigid Plastic | Vinyl | Carpet | Velour & More



MIXING SYSTEMS THOUSANDS OF OEM MATCHED COLORS AT SEMPRODUCTS.COM/EZMIX



50 POPULAR AEROSOL COLORS & 3 CLEARS



CUSTOM FILL™ AEROSOL BLANK (FILLON MACHINE)



UNIVERSAL COLOR COAT BLANK (OMNI-FILL & OTHERS)







## **PRFP** STEP 1

VINYL & PLASTIC: Clean first with SEM Soap and a gray scuff pad. Rinse with water and allow to dry.

For vinyl, clean thoroughly with Vinyl Prep or Zero VOC Surface Cleaner using a clean, damp, lint-free towel and wiping in one direction. For plastic, clean with Plastic & **Leather Prep** or **Zero VOC Surface Cleaner**.

**CARPET & VELOUR:** Shampoo first. Clean with **Plastic** & Leather Prep. Scrub lightly with a nylon bristle brush to separate the fibers and to remove oil, grease and contaminants. Allow to dry, then vacuum.



# **SEM Soap**

A mild abrasive cleaner for flexible substrates.

Part	Size
39362	16 oz. Tube



# **Vinvl Prep**

A strong solvent blend for refinishing vinyl.

Part	Size
38343	16 oz. Aerosol
38344	Quart



# **Plastic & Leather Prep**

A mild solvent blend to clean plastic and leather.

Part	Size
38351	Square Gallon
38353	16 oz. Aerosol
38354	Cone Top Quart

Size

Size

61983 16 oz. Aerosol

Part

Part

13038 Pint

# **STEP 2** MIXING

DO NOT THIN. **Color Coat** is ready to spray.

Shake or stir well, per label instructions, to ensure color uniformity. For best results, use only when can temperature is approximately 70°F (21°C).

For additional versatility when matching low gloss OEM colors, Color Coat Flattener is available.



# **Color Coat** Flattener

An additive that lowers gloss and adds versatility.



# **Custom Fill™ Color Coat Aerosol Blank**

A blank aerosol for filling custom Color Coat colors.



# **Universal Color** Part **Coat Blank**

Size 15993 16 oz. Aerosol

A blank aerosol for filling custom Color Coat colors.



**AEROSOL:** Hold can approximately 6 – 8" from the surface. Apply light coats allowing 5 – 10 minutes between coats.

**SPRAY GUN:** Using fluid tip size 1.0 - 1.3 at 20 - 25 psi with non-HVLP or 8 – 10 psi at the cap with HVLP, apply 2-3 light coats or until hiding, allowing 5-10 minutes flash time between coats. Some colors will require more coats to cover.

**CARPET & VELOUR:** Spray one light coat and immediately brush in all directions using a nylon bristle brush. Apply a second light coat and brush again. After surface has completely dried, brush again to loosen fibers.



# Mixing System **Cone Top**

For the jobber, shop or mobile technician: 9 toners and 3 clears.

Part	Size
27979	Cone Top Quart



# Mixing System **Quart**

For the jobber or shop to start mixing Color Coat.

	0.20	
27989	Quart	
27989	Quart	

Size

27969 Gallon



# Mixing System Gallon

For the jobber or shop that mixes Color Coat regularly.



