



CHIP GUARDS

PROTECT YOUR WORK FROM THE ROAD

- Protects lower panels from impact, chipping, and abrasion
- Duplicates a wide variety of factory textures
- Full texture spectrum from fine to coarse
- Available in aerosol and ready to spray quarts







PREP

Clean surface thoroughly with SEM Solve or XXX **Universal Surface Cleaner.**

Remove any loose paint and sand with 400 grit paper.

Blow off and clean again with SEM Solve or XXX **Universal Surface Cleaner.**



SEM Solve

A virgin solvent blend to clean panels prior to refinish or repair.

Part	Size
38371	Gallon
38373	20 oz. Aerosol
38374	Square Quart



XXX Universal Surface Cleaner

A super compliant. waterborne cleaner that removes solvent and water soluble contaminants prior to refinishing.

Part	Size	
77771	Gallon	
77774	Quart	

STEP 2 APPLY

Refer to the **Technical Data Sheet** for detailed instructions.

Spray 2-3 medium wet coats. Allow 5-10 minutes at 70°F between coats. Close spray distance results in heavier texture while increased spray distance and light coats offer a finer texture.

Allow 2 – 4 hours to dry before topcoating the Clear Chip Guard and Satin Black Chip Guard.

Heavy Texture Chip Guard can be topcoated in 30 – 45 minutes.



Part	Size	Color
39793	20 oz. Aerosol	Opaque
39803	20. oz Aerosol	Clear
39804	Cone Quart	Clear
39813	20 oz. Aerosol	Satin Black
39814	Quart	Satin Black

NOTES

May cause lifting of some top coat refinishes. DO NOT USE over enamel or uncured finishes. Always test for compatibility prior to use.

If clogging develops, remove spray button with a twisting motion and clean with XXX Universal Gun Cleaner. Do not stick pin or other object into can. Gently replace spray button with top of can and spray button pointed away from you.



XXX Universal Gun Cleaner

Part Size 77763 20 oz. Aerosol

A heavy-duty cleaner that removes solvent based and waterborne coatings from spray equipment and aerosol spray tips.



