PANEL & RIVET BONDING STANDARD OPERATING PROCEDURE



Remove spot welds with spot weld cutter. Remove rivets by drilling or grinding. Remove damaged panel and straighten bent flanges with a hammer and dolly.

PRODUCT LIST



PREP

Part	Product	Size
38371	SEM Solve	Gallon
38373	SEM Solve	20 oz. Aerosol
38374	SEM Solve	Square Quart
77771	XXX Universal Surface Cleaner	Gallon
77774	XXX Universal Surface Cleaner	Quart



Dry fit all panels to ensure proper alignment. Drill holes for replacement rivets or mark locations of self-piercing rivets.





Clean with SEM Solve or XXX Universal Surface Cleaner. Grind mating flanges with a 36 grit grinding disc at low speed for aggressive grind mark. Remove any adhesive or protective coatings.

i) If rivet bonding, manufacturers may recommend leaving OEM e-coat on the surface of the new panel. If so, scuff with a red scuff pad.

ADHESIVE

Part	Product	Size
39337	Dual-Mix Door Skin & SMC Adhesive	7 oz. Cartridge
39537	Dual-Mix Weld-Bond Adhesive	7 oz. Cartridge
39747	Dual-Mix Multi-Purpose Panel Adhesive	7 oz. Cartridge

WATCH & LEARN



Apply 3/8" - 1/2" bead of **Dual-Mix**TM **Multi-Purpose Panel Adhesive** or apply 3/8" – 1/2" bead of **Dual-Mix Weld-Bond Adhesive** to both surfaces. Use enough material to completely fill the ioint when parts are clamped. Tool with a spreader or acid brush. Cover all exposed bare metal.

(i) For smaller parts use **Dual-Mix™ Door Skin &** SMC Adhesive.





Clamp panel into place. Do not over clamp. Wipe away excess material.

(i) For maximum bond strength, surfaces must be mated during adhesive's working time.

Clamp panel in place. Install rivets per manufacturer's recommendations during adhesive's working time. Remove clamps after rivets have been installed. Wipe away excess material.



WATCH THE VIDEO AT:

semproducts.com/sop-panelbonding

SEM Products, Inc. Rock Hill, SC 29730 Tech Support: 1-800-831-1122 Customer Care: 1-866-327-7829 semproducts.com

